

# **OWNER'S TECHNICAL MANUAL**

# Oxy Acetylene Hose Reel

## **Description**

The new SO600 oxy acetylene hose reel from Alemlube is a genuine industrial quality welding reel ideal for all general welding applications undertaken by contractors, fabricators and people involved in the construction and industrial fields. Featuring impact resistant UV stabilised covers for maximum durability and an automatic and positive latching mechanism, the SO600 can easily be mounted on the wall or ceiling and can be carried in utes and service vehicles.

## **Specifications**

Uses	Oxy acetylene welding			
Hose Length	15m x 6mm ID hose			
Materials	Plastic UV stabilised cover & steel spring			
Pressure	300 psi (20 bar)			
Weight/Dimensions	630mm (L) x 442mm (H) x 261mm (W)			
Inlet/Outlet	Lead in hose: 5/8" UNF (f) fitting			
Working Temp	-30°C ~ 60°C			

## **Installation Of Reel**


- 1 Prior to mounting the hose reel, ensure that the supply line pressure does not exceed the maximum working pressure of the hose reel.
- 2 Unpack and inspect the reel for damage. Turn by hand to check for smooth operation. Check for completeness.
- 3 For overhead ceiling mounting: Install reel at most 10ft/3m above the floor.
- 4 You will need to purchase appropriate hardware for mounting your new reel.
  - 1) The base has four 6.5mm drilles holes for mounting on a suitable flat surface.
  - 2) Using the four holes in the base, mount the reel in the desired location.

Be sure to use appropriate hardware and tighten securely.

# ag Aemtuse Dogos

## Operation

- 1 Check your S Series reel for correct operation by slowly pulling out the hose. A clicking noise will be heard every half revolution of the drum.
- 2 Latching mode switch, when your S Series reel is in free run state, pull out the hose and allow it to retract after hearing the first, second or third click.
- 3 To unlatch the reel, slowly pull out the hose until the clicking noise stops, and then let the hose retract unitl the hose stop rests against the hose guide.
- 4 If necessary, adjust spring tension on reel by adding or removing wraps of hose from spool, one wraps at a time, until desired tension is obtained. Add wraps to increase tension. Remove wraps to decrease tension.




### Warning

- 1. Make sure the hose is in proper working order.
- 2. Clean the hose with a cloth dipped in hot water to remove dirt or deposits and ensure correct rewinding.
- 3. Do not use detergents or solvents which could prove incompatible with cable-winder materials.
- 4. Dismantling of the unit by unskilled person could prove hazardous: the risk involved mainly concern the preloaded springs.

					HANTY
NSW	QLD/PNG	VIC/TAS	WA	SA/NT	NZ
TEL: (02) 9677 1555	TEL: (07) 3204 9166	TEL: (03) 8787 8288	TEL: (08) 9302 4199	TEL: (08) 8241 7111	TEL: (09) 447 1007
FAX: (02) 9675 1555	FAX: (07) 3204 1224	FAX: (03) 8787 8266	FAX: (08) 9303 2095	FAX: (08) 8241 7011	FAX: (09) 447 1008

# Parts and Drawing Breakdown For SO600 Hose Reels



## Ordering Spare Parts SO600 Spare Parts List

Item No.	Part No.	Description	QTY	Item No.	Part No.	Description	QTY
1	SO600-1	Cover	2	16	SO600-16	Big Cover	2
2	SO600-2	Screw	3	17	SO600-17	Small Cover	1
3	SO600-3	Screw	8	18	SO600-18	Ratchet Spring	1
4	SO600-4	Main Axle	1	19	SO600-19	Screw	3
5	SO600-5	Washer	1	20	SO600-20	Washer	3
6	SO600-6	Ratchet Ring	2	21	SO600-21	Clip for Ratchet	1
7	SO600-7	Drum	2	22	SO600-22	Ratchet	1
8	SO600-8	Hose Assembley	1	23	SO600-23	Stator	1
9	SO600-9	Bracket	1	24	SO600-24	Axle	1
10	SO600-10	Cover for Axle	1	25	SO600-25	Swivel Assembly	1
11	SO600-11	Screw	8	26	SO600-26	Cover for Spool	1
12	SO600-12	Guide Protector	1	27	SO600-27	Screw	4
13-1		Hose Stop	2	28	SO600-28	Inlet Hose Assembly	1
13-2	SO600-13-1-2-3-4	Screw	2	29	SO600-29	Spring for Hose	2
13-3		Washer	2	30	SO600-30	Washer	2
13-4		Nut	2	31	SO600-31	Screw	3
14	SO600-14	Screw	10	32	SO600-32	Main Spring	1
15	SO600-15	Nut	10	33	SO600-33	Clamp for main Spring	1

NSW TEL: (02) 9677 1555 FAX: (02) 9675 1555 QLD/PNG TEL: (07) 3204 9166 FAX: (07) 3204 1224 VIC/TAS TEL: (03) 8787 8288 FAX: (03) 8787 8266

TEL: (08) 9302 4199 FAX: (08) 9303 2095 SA/NT TEL: (08) 8241 7111 FAX: (08) 8241 7011

TEL: (09) 447 1007 FAX: (09) 447 1008